



| v3 - LEED 2009

## Stormwater quantity control

SSc6 | Possible 1 point

Glossary

### Intent

To limit disruption of natural hydrology by reducing impervious cover, increasing on-site infiltration, reducing or eliminating pollution from stormwater runoff and eliminating contaminants.

### Requirements

#### Option 1

During the performance period, implement a stormwater management plan that infiltrates, collects and reuses runoff or evapotranspirates runoff from at least 15% of the precipitation falling on the whole project site both for an average weather year and for the 2-year, 24-hour design storm.

Implement an annual inspection program of all stormwater management facilities to confirm continued performance. Maintain documentation of inspection, including identification of areas of erosion, maintenance needs and repairs. Perform all routine required maintenance, necessary repairs or stabilization within 60 days of inspection.

#### OR

#### Option 2

Use Low Impact Development (LID)<sup>1</sup> practices to capture and treat water from 25% of the impervious surfaces for the 95th percentile of regional or local rainfall events.

Implement an annual inspection program of all stormwater management facilities to confirm continued performance. Maintain documentation of inspection, including identification of areas of erosion, maintenance needs and repairs. Perform all routine required maintenance, necessary repairs or stabilization within 60 days of inspection.

<sup>1</sup>Low impact development (LID) is an approach to managing stormwater runoff that emphasizes on-site natural features to protect water quality by replicating the natural land cover hydrologic regime of watersheds and addressing runoff close to its source. Examples include better site design principles such as minimizing land disturbance, preserving vegetation, minimizing impervious cover, and design practices like rain gardens, vegetated swales and buffers, permeable pavement, rainwater harvesting, and soil amendments. These are engineered practices that may require specialized design assistance.

### Alternative Compliance Paths (ACPs)



[LEED 2009 EBOM reference guide supplement with India ACPs](#)



[LEED 2009 EBOM reference guide supplement with India ACPs](#)