



| v2 - Schools 2007

Fundamental refrigerant management

EAp3 | Required

Glossary

Intent

Reduce ozone depletion.

Requirements

Zero use of CFC-based refrigerants in new base building HVAC&R systems. When reusing existing base building HVAC equipment, complete a comprehensive CFC phase-out conversion prior to project completion. Phase-out plans extending beyond the project completion date will be considered on their merits.