



Low-emitting materials - adhesives and sealants

EQc4.1 | Possible 1 point

Intent

Reduce the quantity of indoor air contaminants that are odorous or potentially irritating to provide installer and occupant health and comfort.

Requirements

Adhesives must meet or exceed the VOC limits of South Coast Air Quality Management District Rule #1168 by, AND all sealants used as a filler must meet or exceed Bay Area Air Quality Management District Reg. 8, Rule 51.