

## Fundamental refrigerant management

---

EAp3 | Required

### Intent

Reduce ozone depletion

### Requirements

Zero use of CFC-based refrigerants in new base building HVAC&R systems and free-standing and/or plug-in equipment. When reusing existing base building HVAC equipment, complete a comprehensive CFC phase-out conversion prior to project completion. Phase-out plans extending beyond the project completion date will be considered on their merits.