LEED BD+C: New Construction | v4

Enhanced commissioning

Possible 6 points

Glossary

Intent

To further support the design, construction, and eventual operation of a project that meets the owner's project requirements for energy, water, indoor environmental quality, and durability.

Requirements

Implement, or have in place a contract to implement, the following commissioning process activities in addition to those required under EA Prerequisite Fundamental Commissioning and Verification.

Commissioning authority

- The CxA must have documented commissioning process experience on at least two building projects with a similar scope of work. The experience must extend from early design phase through at least 10 months of occupancy;
- The CxA may be a qualified employee of the owner, an independent consultant, or a disinterested subcontractor of the design team.

Option 1. Enhanced systems commissioning (3-4 points)

Path 1: Enhanced commissioning (3 points)

Complete the following commissioning process (CxP) activities for mechanical, electrical, plumbing, and renewable energy systems and assemblies in accordance with ASHRAE Guideline 0–2005 and ASHRAE Guideline 1.1–2007 for HVAC&R systems, as they relate to energy, water, indoor environmental quality, and durability.

The commissioning authority must do the following:

- Review contractor submittals.
- Verify inclusion of systems manual requirements in construction documents.
- Verify inclusion of operator and occupant training requirements in construction documents.
- Verify systems manual updates and delivery.
- Verify operator and occupant training delivery and effectiveness.
- Verify seasonal testing.
- Review building operations 10 months after substantial completion.
- Develop an on-going commissioning plan.

Include all enhanced commissioning tasks in the OPR and BOD.

OR

Path 2: Enhanced and monitoring-based commissioning (4 points)

Achieve Path 1.

AND

Develop monitoring-based procedures and identify points to be measured and evaluated to assess performance of energy- and water-consuming systems.

Include the procedures and measurement points in the commissioning plan. Address the following:

- roles and responsibilities;
- measurement requirements (meters, points, metering systems, data access);
- the points to be tracked, with frequency and duration for trend monitoring;
- the limits of acceptable values for tracked points and metered values (where appropriate, predictive algorithms may be used to compare ideal values with actual values);
- the elements used to evaluate performance, including conflict between systems, out-of-sequence operation of systems components, and energy and water usage profiles;
- an action plan for identifying and correcting operational errors and deficiencies;
- training to prevent errors;
- planning for repairs needed to maintain performance; and
- the frequency of analyses in the first year of occupancy (at least quarterly).

Update the systems manual with any modifications or new settings, and give the reason for any modifications from the original design.

AND/OR

Option 2. Envelope commissioning (2 points)

Fulfill the requirements in EA Prerequisite Fundamental Commissioning and Verification as they apply to the building's thermal envelope in addition to mechanical and electrical systems and assemblies.

Complete the following commissioning process (CxP) activities for the building's thermal envelope in accordance with ASHRAE Guideline 0–2005 and the National Institute of Building Sciences (NIBS) Guideline 3–2012, Exterior Enclosure Technical

Requirements for the Commissioning Process, as they relate to energy, water, indoor environmental quality, and durability.

Commissioning authority must complete the following:

- Review contractor submittals.
- Verify inclusion of systems manual requirements in construction documents.
- Verify inclusion of operator and occupant training requirements in construction documents.
- Verify systems manual updates and delivery.
- Verify operator and occupant training delivery and effectiveness.
- Verify seasonal testing.
- Review building operations 10 months after substantial completion.
- Develop an on-going commissioning plan.