



| v2 - LEED 2.0

## Stormwater design - quantity control

SSc6.1 | Possible 1 point

Glossary

### Intent

Limit disruption of natural hydrology by reducing impervious cover, increasing on-site infiltration, and managing stormwater runoff.

### Requirements

#### Case 1 - existing imperviousness is less than or equal to 50%

1. Discharge rate and quantity

Implement a stormwater management plan that prevents the post-development peak discharge rate and quantity from exceeding the pre-development peak discharge rate and quantity for the one- and two-year 24-hour design storms.

**OR**

2. Stream channel protection

Implement a stormwater management plan that protects receiving stream channels from excessive erosion by implementing a stream channel protection strategy and quantity control strategies.

**OR**

#### Case 2 - existing imperviousness is greater than 50%

Implement a stormwater management plan that results in a 25% decrease in the volume of stormwater runoff from the two-year 24-hour design storm.