



Enhanced refrigerant management

Possible 1 point

Intent

To reduce ozone depletion and support early compliance with the Montreal Protocol while minimizing direct contributions to climate change.

Requirements

Option 1. No refrigerants or low-impact refrigerants (1 point)

Do not use refrigerants, or use only refrigerants (naturally occurring or synthetic) that have an ozone depletion potential (ODP) of zero and a global warming potential (GWP) of less than 50.

OR

Option 2. Calculation of refrigerant impact (1 point)

Select refrigerants that are used in heating, ventilating, air-conditioning, and refrigeration (HVAC&R) equipment to minimize or eliminate the emission of compounds that contribute to ozone depletion and climate change. The combination of all new and existing base building and tenant HVAC&R equipment that serve the project must comply with the following formula:

IP units						SI units							
LCGWP	+	LCODP	x	10 ⁵	≤	100	LCGWP	+	LCODP	x	10 ⁵	≤	13

Calculation definitions for LCGWP + LCODP x 10 ⁵ ≤ 100 (IP units)	Calculation definitions for LCGWP + LCODP x 10 ⁵ ≤ 13 (SI units)
LCODP = [ODPr x (Lr x Life +Mr) x Rc]/Life	LCODP = [ODPr x (Lr x Life +Mr) x Rc]/Life
LCGWP = [GWPr x (Lr x Life +Mr) x Rc]/Life	LCGWP = [GWPr x (Lr x Life +Mr) x Rc]/Life
LCODP: Lifecycle Ozone Depletion Potential (lb CFC 11/Ton-Year)	LCODP: Lifecycle Ozone Depletion Potential (kg CFC 11/(kW/year))
LCGWP: Lifecycle Direct Global Warming Potential (lb CO2/Ton-Year)	LCGWP: Lifecycle Direct Global Warming Potential (kg CO2/kW-year)
GWPr: Global Warming Potential of Refrigerant (0 to 12,000 lb CO2/lbr)	GWPr: Global Warming Potential of Refrigerant (0 to 12,000 kg CO2/kg r)
ODPr: Ozone Depletion Potential of Refrigerant (0 to 0.2 lb CFC 11/lbr)	ODPr: Ozone Depletion Potential of Refrigerant (0 to 0.2 kg CFC 11/kg r)
Lr: Refrigerant Leakage Rate (2.0%)	Lr: Refrigerant Leakage Rate (2.0%)
Mr: End-of-life Refrigerant Loss (10%)	Mr: End-of-life Refrigerant Loss (10%)
Rc: Refrigerant Charge (0.5 to 5.0 lbs of refrigerant per ton of gross AHRI rated cooling capacity)	Rc: Refrigerant Charge (0.065 to 0.65 kg of refrigerant per kW of AHRI rated or Eurovent Certified cooling capacity)
Life: Equipment Life (10 years; default based on equipment type, unless otherwise demonstrated)	Life: Equipment Life (10 years; default based on equipment type, unless otherwise demonstrated)

For multiple types of equipment, calculate a weighted average of all base building HVAC&R equipment, using the following formula:

IP units		SI units	
$\sum (LCGWP + LCODP \times 10^5) \times Q_{unit}$	≤ 100	$\sum (LCGWP + LCODP \times 10^5) \times Q_{unit}$	≤ 13
Qtotal		Qtotal	

Calculation definitions for $[\sum (LCGWP + LCODP \times 10^5) \times Q_{unit}] / Q_{total} \leq 100$ (IP units)	Calculation definitions for $[\sum (LCGWP + LCODP \times 10^5) \times Q_{unit}] / Q_{total} \leq 13$ (SI units)
--	---

Qunit = Gross AHRI rated cooling capacity of an individual HVAC or refrigeration unit (Tons)

Qunit = Eurovent Certified cooling capacity of an individual HVAC or refrigeration unit (kW)

This website collects and uses cookies to ensure you have the best user experience. Please click on the "Accept and Close" button to affirm your consent and continue to use our website. For more information, please view our [Cookies Statement](#).

Accept and Close